



## Traditional systems - Angle standing seam (vertical design)

### ASS V 3.1.01 Ground level foot.





All dimensions are indicative unless specified on the drawing Sheet thickness may be exaggerated for clarity

#### Scale 1/4

# Notes:

- 'A' shows foot of seam finished according to ASS V 1.2.1.01a.
- 'B' shows foot of seam finished according to ASS V 1.2.1.01b.
- In absence of local or national regulations, a gap of 150mm is recommended between the ground and the bottom edge of the cladding.
- Generic structural details are given for indicative purposes only.
- 1. elZinc® cladding
- Membrane 2.
- Structural underlay 3.
- 4. Folded galvanised steel profiles

elZinc®


- 5. elZinc® perforated sheet
- 6. elZinc® retention profile
- 7. Insulation
- 8. Wooden batten
- 9. Wall bracket
- 10. Substrate






## Traditional systems - Angle standing seam (vertical design)

### ASS V 3.1.01 Ground level foot.





All dimensions are indicative unless specified on the drawing Sheet thickness may be exaggerated for clarity

#### Scale 1/4

# Notes:

- 'A' shows foot of seam finished according to ASS V 1.2.1.01a.
- 'B' shows foot of seam finished according to ASS V 1.2.1.01b.
- In absence of local or national regulations, a gap of 150mm is recommended between the ground and the bottom edge of the cladding.
- Generic structural details are given for indicative purposes only.
- 1. elZinc® cladding
- Membrane 2.
- Structural underlay 3.
- 4. Folded galvanised steel profiles

elZinc®

- 5. elZinc® perforated sheet
- 6. elZinc® retention profile
- 7. Insulation
- 8. Wooden batten
- 9. Wall bracket
- 10. Substrate